+135-3858-6433 (GuangDong) +188-1699-6168 (ShangHai) +852-6957-5415 (HongKong)



# SABIC® PP PHC27

# PP IMPACT COPOLYMER

# **DESCRIPTION**

SABIC<sup>®</sup> PP PHC27 combines very high impact resistance, also at low temperatures, with a good stiffness and offers very good flow properties. Thanks to very low tendency to warp, it is typically used for injection moulding of crates & boxes, suitcase shells and automotive parts.

#### **TYPICAL PROPERTY VALUES**

PROPERTIES	TYPICAL VALUES	UNITS	TEST METHODS
POLYMER PROPERTIES			
Melt Flow Rate			
at 230 °C and 2.16 kg	14	dg/min	ISO 1133
Density	905	kg/m³	ASTM D1505
FORMULATION			
UV stabilized		-	
Anti static agent		-	-
Nucleating agent		-	-
MECHANICAL PROPERTIES			
Tensile test			
strain at yield <sup>(1)</sup>	6	%	ISO 527-2 1A
stress at yield	21	MPa	ISO 527-2 1A
tensile modulus <sup>(2)</sup>	1000	MPa	ISO 527-2 1A
Izod impact notched			
at 0 °C	13	kJ/m²	ISO 180/1A
at -20 °C	9	kJ/m²	ISO 180/1A
Izod impact notched			
at 23 °C	No Break	kJ/m²	ISO 180/1A
Charpy Impact Strength Notched			
at 0 °C	15	kJ/m²	ISO 179/1eA
at -20 °C	8	kJ/m²	ISO 179/1eA
at 23 °C	60	kJ/m²	ISO 179/1eA
Charpy impact unnotched			
at 23 °C	No Break	kJ/m²	ISO 179/1eU
Hardness Shore D	60	-	ISO 868
THERMAL PROPERTIES			
Heat deflection temperature (3)			
at 0.45 MPa (HDT/B)	80	°C	ISO 75

+135-3858-6433 (GuangDong) +188-1699-6168 (ShangHai) +852-6957-5415 (HongKong)



PROPERTIES	TYPICAL VALUES	UNITS	TEST METHODS
at 1.80 MPa (HDT/A)	50	°C	ISO 75
Vicat Softening Temperature (4)			
at 10 N (VST/A)	145	°C	ISO 306
at 50 N (VST/B)	65	°C	ISO 306

- (1) Speed of testing: 50 mm/min
- (2) Speed of testing: 1 mm/min
- (3) Flat wise (testbar 80\*10\*4mm)
- (4) Temperature rate: 120°C/h

# **QUALITY**

SABIC Europe is fully certified in accordance with the internationally accepted quality standard ISO9001

# STORAGE AND HANDLING

Avoid prolonged storage in open sunlight, high temperatures (<50 °C) and /or high humidity as this could well speed up alteration and consequently loss of quality of the material and /or its packaging. Keep material completely dry for good processing.